



Device	function
B1	proximity switch "beginning of the belt"
B2	proximity switch "end of the belt"
F1	main fuse
F2	fuse "control circuit"
F3	fuse "load circuit"
P1	optical indicator "fault"
P2	accustical indicator "fault"
Q1,Q2,Q3	aux. contact "motor protection 1-3"
S0	main switch
S1	pushbutton "Start"
S2	pushbutton "Stop"
S6	pushbutton "run empty"
S7	switch "emergency stop"
S8	pushbutton "fault reset"
T1	control voltage generation