



Equipment	Name
A1	easy719-AC-RC
A2	easy618-AC-RE
F1	Fuse "load circuit"
F2	Fuse "control circuit"
S1	Pushbutton "Shutter 1 open"
S2	Pushbutton "Shutter 1 closed"
S3	Pushbutton "Shutter 2 open"
S4	Pushbutton "Shutter 2 closed"
S5	Pushbutton "Shutter 3 open"
S6	Pushbutton "Shutter 3 closed"
S7	Pushbutton "Shutter 4 open"
S8	Pushbutton "Shutter 4 closed"
S9	Pushbutton "Shutter 5 open"
S10	Pushbutton "Shutter 5 closed"
S11	Pushbutton "Shutter 6 open"
S12	Pushbutton "Shutter 6 closed"
S13*	Keyswitch *
	"Disable outputs"

\* S13 can be "saved" by connecting L1 (behind F2) and R1.  
This Prevents the ability to disable output signals (see description text).