

Device	function
F1	main fuse
F2	fuse "control circuit"
F3	fuse "loadcircuit"
K1	contactor "motor 1 clockwise"
K2	contactor "motor 1 anti-clockwise"
K3	contactor "motor 2 clockwise"
K4	contactor "motor 2 anti-clockwise"
Q1	aux. contact "Motor-protective for motor M1"
Q2	aux. contact "Motor-protective for motor M2"
S0	main switch
S1	switch "ON/OFF"
S2	switch "direction change"
S5	push button "start"
T1	control voltage generation