

Device	function
F1	main fuse
F2	fuse "control-circuit"
F3	fuse "loadcircuit"
M1	motor "pump 1"
M2	motor "pump 2"
M3	motor "pump 3"
S0	main switch
S1	level switch "minimun & maximum level "
S3	aux. contact "twilight switch"
S4	switch "Auto- ON"
T1	control voltage generation