



Device	function
F1	fuse "load circuit"
F2	fuse "control circuit"
H1	signal light "Alert signal"
M1	motor "agitation motor"
P1	horn "Alert signal"
S1	switch "Start/Stop"
S2	selector switch "HAND/AUTO"
S3	pushbutton "Alarm-reset"
S4	auxillary contact "Motor-protective circuit-breaker"
S5	pushbutton "Fault Alarm Test"